


# Oil-Fired **STANLEY** De-Luxe 90



To ensure safety, satisfaction and maximum service, this quality Cooker should be installed by a trained and competent installer. The provision of a Central Heating facility, requires that the hot water systems involved, conform fully to good plumbing practice and established standards.

## **INSTALLATION AND OPERATING INSTRUCTIONS**

Issued by People Printing Ltd. : 656 2102




## INTRODUCTION

Congratulations on purchase of this fine Irish made Oil-fired Central Heating Cooker. It is built to our usual high standards and it will give you every satisfaction in use.

Please read the following instructions before operating this excellent product.

This fine Irish made Oil-fired Central Heating Cooker. It is built to our usual high standards and it will give you every satisfaction in use.

Please read the following instructions before operating this excellent product.



1. Plate Rack (to order)
2. Splash Back (to order)
3. Hot Plate Cover
4. Hot Plate
5. Simmer Plate
6. Hob
7. Thermostat Control Panel
8. Towel Rail
9. Fire Door
10. Oven Door
11. Warming Drawer
12. Side Flue Cleaning Plate
13. Front Cleaning Door
14. Burner Cover Plate
15. Hob Blanking-off Plate




Boiler capacity: 5.6 Litres = 1.25 Gallons  
Cooker weight: 338 kgs. = 743 lbs.

The Manufacturers reserve the right to make alterations to design, materials or construction for manufacturing or other reasons subject to publication.

alterations to design, materials or construction subject to publication.

## SPECIFICATION




DIMENSIONS	A	B	C	D	E	F	G	H	J	K	L	M	N	P
METRIC (MILLIMETRES)	920	889	568	505	283	734	442	630	230	50	1425	1" BSP	127	205
IMPERIAL (INCHES)	36 $\frac{1}{4}$	35	22 $\frac{3}{8}$	20	11 $\frac{1}{8}$	28 $\frac{7}{8}$	17 $\frac{3}{8}$	24 $\frac{3}{4}$	8 $\frac{7}{8}$	2	56 $\frac{1}{8}$	1" BSP	5"	8 $\frac{1}{8}$

FEATURE	METRIC	IMPERIAL
HOT PLATE	368 x 252	14 $\frac{1}{2}$ " x 10"
SIMMER PLATE	390 x 246	15 $\frac{3}{8}$ " x 9 $\frac{3}{4}$ "
OVEN	400W x 324H x 396D	15 $\frac{3}{4}$ "W x 12 $\frac{3}{4}$ "H x 15 $\frac{3}{8}$ "D
WARMING OVEN	390W x 290H x 440D	15 $\frac{3}{8}$ "W x 11 $\frac{3}{8}$ "H x 17 $\frac{1}{4}$ "D

Cooker Output: At 1.8 Kg = 2.08 Litres Kerosene/Hour  
 Gross Output: 20 KW = 69,000 BTUs/Hour  
 Net To Water: 13.7KW = 47,000 BTUs/Hour (Max.)  
 Jet: 60 Degree Hollow Pattern (0.55 U.S. gallons)  
 Oil Pressure: 8.16 Atmospheres = (120 p.s.i.)  
 Radiation Surface: Heating Surface only 22.2 sq. metres = 240 sq. ft.  
                               Heating and Domestic Hot Water 19.4 sq. metres = 210 sq. ft.



## INSTALLATION



### PRE-INSTALLATION CHECK

Before installing your new Cooker, check that the chimney is clean and clear of obstructions. Cracked brickwork and leaking joints should be made good. The chimney should have a cross-sectional area of at least 176 sq. cm. or an inner diameter of 15 to 23 cm. A similar direct air inlet is required in the room to support combustion.

Where flue piping passes through a closure plate with sliding door, ensure that the pipe continues up and is ultimately connected to the flue liner and well sealed with fire cement.

Do not connect to a chimney serving another appliance. Always ensure that the connection is to a chimney of the same size — never connect to one of smaller dimensions. Chimneys wholly constructed of single skin pipe are not recommended under any circumstances. Due to their inability to retain heat such chimneys will inevitably give rise to the formation of condensation.


### COOKER CLEARANCE

The cooker should not be installed at zero clearance to combustible materials. The hob should have a minimum clearance of at least 7.5 cm. from combustible materials unless otherwise fully insulated.

When the Cooker is backed against a wall of combustible material it should have adequate protection in the form of non-combustible millboard covered with sheet steel.

### CHIMNEY HEIGHT

The flue must be high enough (more than 4.6 m. in any case) to allow the flue gases to vent into clean air, away from the turbulence that may be caused by roof structures, other chimney stacks, etc. The venting position should be 1.0 m. above any obstruction within a 7.6 m. radius.



### THERMOSTAT CONTROL PANEL

When you unpack the cooker the control panel will be fitted into a socket in the back of the cooker. Swing the control panel out of this recess and place it on the hob. Fix it in position with the two screws and gasket provided.

Be careful not to damage any of the electrical connections and capillary tubes when fitting on the control panel.



Where the standard masonry chimney is not available, a proprietary type of twin wall, fully insulated pipe may be used. As already stated, the minimum inner diameter must not be less than 15 cm. and the pipe must terminate at a point not lower than the main ridge or adjacent outside obstructions. With such installations, access to the chimney must be provided for cleaning purposes.

## FLUE PIPES




Square bends and long horizontal runs of flue piping must be avoided. A Back outlet Pipe is provided with the cooker. A Top outlet Pipe is available. **ALL FLUE CONNECTIONS MUST BE THOROUGHLY SEALED.** Blocked chimneys are dangerous, use only recommended fuels, keep chimneys and flue ways clear; read the operating instructions.

## CHIMNEY CLEANING

Whichever type of flue is chosen, there must be cleaning access to the whole flue system. The flue of the chimney will need to be cleaned regularly. How often will depend a lot on how your Cooker is run, but, to start with, make a point of inspecting the flue system every six months. This period may well be extended as time goes by if there is little sign of deposits.

## HEARTH CONSTRUCTION

When a properly constructed hearth is not available we recommend that the Cooker be placed on a slab or foamed concrete 4 cm or a slab of other insulating material. This hearth must extend at least 45 cm to the front and 30 cm each side.



## DRAUGHT REQUIREMENTS

When a draught recorded is over .06 inches W.G. a draught stabiliser should be fitted on the outside wall of the chimney or fit a cowl to the chimney top.

**Remember, a proper flue is necessary for the efficient operation of your Oil Cooker to provide a steady draught of between .04 and .06 inches W.G.**

The cooker is fitted with a pressure Jet burner and will not be affected by down-draught conditions.




## PLUMBING

RADIATOR HEATING CIRCUITS	FIRST FLOOR
	GROUND FLOOR
CYLINDER HEATING CIRCUIT	FIRST FLOOR

FUNCTION		PIPE	FUNCTION
PUMPED	FLOW TO RADIATORS	7	HOT WATER FLOW
PUMPED	RETURN EX "	8	COLD WATER (EX TANK)
PUMPED	FLOW TO RADIATORS	9	COLD FEED-HEAT SYSTEM
PUMPED	RETURN EX "	10	OPEN VENT-HEAT SYSTEM
GRAVITY	FLOW TO CYLINDER	11	COLD FEED TO CYLINDER
GRAVITY	RETURN EX "	12	HOT WATER VENT
		13	MAINS WATER
		T	THERMOSTAT
		X	ISOLATING VALVES

This diagram illustrates the basic principles of water systems and is not to be regarded as a working drawing.



Recommended indirect cylinder 135 litres each in length. Cylinder and pipe work

should be lagged to minimise heat losses.

### REGULATIONS

The Plumbing must be in accordance with all relevant regulations and practices. It must include a gravity circuit with expansion pipe, open to the atmosphere. The central heating will normally be pump-driven as with other types of boiler. The system is thermostatically controlled by the Thermostat mounted on the Cooker Hob.

### BOILER OUTPUT

High output cannot be maintained unless fuel is being burned at a rate of 2.08 Litres per hour of Kerosene.


### GRAVITY CIRCUIT

The gravity circuit consists of the domestic hot water tank of 135 — 180 litres indirect cylinder, fixed in an upright position, recommended for hot water storage and it should be connected to the boiler by 25 mm diameter flow and return piping. The pipes should not exceed 7.8 m. each in length and anything in excess of 4.6 m. must be fully lagged. The shorter the run of pipe work the more effective the water heating efficiency and to this end, the cylinder should be fully lagged. For safety's sake do not have any valves on this circuit.




## INJECTOR TEE

Where the gravity and central heating circuits join together to return to the Cooker we recommend the use of an injector tee connection, situated as close to the unit as possible. This type of tee encourages a stable flow of hot water through both circuits and helps to prevent priority being given to the stronger flow, which is most commonly the pumped central heating circuit. This way, there will be no shortage of hot water to the taps when the heating is on.



## WATER CIRCUIT TEMPERATURE


The return water temperature should be maintained at not less than 40°C. so as to avoid condensation on the boiler and return piping. Fitting a pipe thermostat to the flow pipe of the gravity circuit and wiring it into the pump control will ensure rapid circulation of the hot water to avoid premature burner shut down being activated by the Cooker thermostat.



## PIPE THERMOSTAT

The fitting of a pipe thermostat to the flow pipe is absolutely essential in order to activate the water circulation pump when the water reaches the selected temperature.

When the water temperature falls below the selected temperature the pipe thermostat will cut off the water circulation pump in order to allow the boiler to recover. Ensure that the pipe thermostat is fitted on the flow pipe and as close as possible to the cooker. The recommended setting should be between 45°C. and 55°C.




## FUEL CALORIFIC VALUES

**Kerosene 28 sec. —**

Calorific Value: 8354 Calories = 33,150 BTUs per Litre/Hour.

## FUEL INSTALLATION



### FUELS

THE RECOMMENDED FUEL FOR THE COOKER BURNER IS KEROSENE 28 SECOND VISCOSITY FUEL OIL.

Gas Oil 35 second viscosity is not recommended due to high servicing requirements, the possibility of coagulation in severe cold weather conditions. The burner is not suitable for use with diesel oil due to premature blocking of the pump and injector by inhibitors in the fuel.

If possible, purchase fuel from the same source each time.

### FUEL SUPPLY LINE

Pipes should consist of copper tubing (NEVER

galvanised steel), the final connection to the burner pump inlet port being made with the length of flexible pipe supplied with the burner. Joints should be made with compression fittings, not by soldering.

When gravity feed is used (the most common), the maximum head should not exceed 4 m. (equivalent to a pressure of 35 kPa). Note that the pump is factory set for single pipe installation.


IT IS ABSOLUTELY ESSENTIAL THAT A SUITABLE FIRE SAFETY VALVE BE FITTED ON THE OIL SUPPLY LINE BETWEEN THE COOKER AND OIL FILTER, ADJACENT TO THE COOKER.

galvanised steel), the final connection to the burner pump inlet port being made with the length of flexible pipe supplied with the burner. Joints should be made with compression fittings, not by soldering.

When gravity feed is used (the most common), the maximum head should not exceed 4 m. (equivalent to a pressure of 35 kPa).

Note that the pump is factory set for single pipe installation.



IT IS ABSOLUTELY ESSENTIAL THAT A SUITABLE FIRE SAFETY VALVE BE FITTED ON THE OIL SUPPLY LINE BETWEEN THE COOKER AND OIL FILTER, ADJACENT TO THE COOKER.





## OPERATION

1. Ensure that the control panel thermostats are in the "off" position.
2. Switch on the mains electric supply.
3. Turn on the oil supply.
4. Select the heating mode required by opening the fire door and moving the boiler baffle levers with the tool provided, to the required position.



### Setting A. High Boiler Output with Hot Plate and Oven.

1. Move the Left-hand Control Lever to the right.
2. Set the **Oven** thermostat to Idle.
3. Set the Boiler thermostat to required temperature.

### Setting B. High Hotplate Output, with Boiler and Oven.

1. Move Left-hand Control Lever to the left and move Right-hand Control Lever to the right.
2. Set the **Oven** thermostat to Idle.
3. Set the Boiler thermostat as required.

### Setting C. High Oven Output with Hot Plate and Low Boiler Output.

1. Move Right-hand Control Lever to the left.
2. Set the **Boiler** thermostat to Idle.
3. Set the Oven thermostat to the required cooking temperature.

**Pilot Light.** Red Pilot Light will go out when oven reaches temperature selected.

**Reset Button.** Green thermostat reset button will pop out if thermostat settings are exceeded.


To reset — press button **inwards**.

To switch off. Turn **both** thermostats to off.



## BURNER DOES NOT IGNITE

- Check (a) that electricity is switched on;
- Check (b) that oil supply valve is open;
- Check (c) that the green thermostat reset button is pressed in;
- Check (d) that the burner reset button (located inside warming drawer) glows red.



## OVEN

The MAIN OVEN is heated on four faces and it will cook food evenly when baking or roasting on Setting C. The warming compartment is heated on top face only, and it is ideal for heating and keeping food ready for serving.

## CENTRAL HEATING

The boiler output is determined by the position of the boiler baffles as follows:

- Setting A: Max output 13.7KW 100 BTUs.
- Setting B: Max output 7.9KW 100 BTUs.
- Min. output 4.4KW 100 BTUs.
- Setting C: Max. output 3.7KW 100 BTUs.
- Min. output 2.3KW 100 BTUs.

(The above may vary slightly depending on individual installation conditions).

The boiler therefore will operate at its maximum output at Setting A of the controls, with the thermostat turned up to 90°C. A range of outputs from the boiler may be obtained to suit individual requirements by adjusting the thermostat between 50°C and 90°C.

## SUMMER SETTING

For Summer use and lower boiler output Use Setting C. When using the oven in this position turn the oven thermostat to the required temperature.

## HOT PLATE


The hot plate is machine graded for maximum heating efficiency and it is temperature graded, the left-hand side over the burner being the best at settings A and B and the right-hand side is suitable for simmering. For maximum hotplate temperature use Setting B.

## EXTERNAL AUTOMATIC TIMESWITCH

The cooker may be connected to an external automatic timeswitch which will control the light up and shut down operation period of the cooker.

## ROOM THERMOSTAT

The Cooker may be connected to a room thermostat in order to maintain an overall even temperature.




## COOKING UTENSILS

For best cooking results and economy of operation use heavy based, flat bottomed utensils.

## HOT PLATE INSULATING COVER

The insulating cover retains most of the heat that would otherwise be radiated into the kitchen. It also retains the heat in the hotplate so that rapid heating of cooking utensils will occur when it is lifted for cooking purposes.



## CONDENSATION

If the Cooker is run for extended periods on the low settings the unit can cool down to an extent that vapour in the flue gases may condense.

This will make the inside of the flueways damp, creating a sooty deposit which will reduce the efficiency of the appliance.

It is best to run the cooker occasionally at the higher settings in order to prevent the formation of condensation.



## SERVICING


Provided that the Cooker has been operated normally and that the correct grade of oil has been used it will be found that the burner and cooker flueways will not need servicing until approximately every six to twelve months.

We recommend that the Cooker and Burner be serviced by an authorised STANLEY service agent. Your STANLEY distributor will let you have the name of your local service agent.

**TO SERVICE THE COOKER, THE FOLLOWING PROCEDURE SHOULD BE ADOPTED.**


### WARNING!

**SWITCH OFF ELECTRICAL AND OIL SUPPLY TO THE COOKER.**




## FLUE CLEANING

1. Remove the 3 retaining screws from the Hot Plate (No. 4) and Simmer Plate (No. 5) and also the screw of the simmer cleaning plate (No. 12). Remove hotplate and cleaning panels. Remove the front cleaning door (No. 13).
2. All deposits from the top of the oven may be brushed down the right-hand side of the oven. Deposits which have accumulated on the right-hand side of the oven should also be brushed downwards.
3. To remove these deposits thoroughly, clean out the residue from the side flue and base plate through the front cleaning door opening.
4. **Ensure that all plates and cleaning panels are thoroughly re-sealed with fresh fire cement when being refitted.**




Replace all parts and tighten screws.



## BURNER SERVICING

**WARNING — SWITCH OFF ELECTRICAL AND OIL SUPPLY TO THE COOKER.**


1. Remove the 3 Screws and Hot Plates from the cooker as in Flue Cleaning operation.



2. To remove the burner take out the four screws from the Cover Plate (No. 14). **Break the cement seal** and remove the plate. Remove the 2 outer screws from the back plate of the burner carrier from inside the Fire Box and withdraw the burner assembly complete.

Care should be taken not to damage the electrical and oil leads connected to the burner.


3. The burner may now be serviced by a competent engineer. See pages 11-14.



4. To clean deposits from the boiler baffles set them to position B and clean both sides down into firebox. Remove all soot deposits from the boiler and generally clean out firebox area. It is helpful to use a vacuum cleaner to collect dust deposits that will have accumulated.
5. Care should be taken when refitting the burner assembly that the insulation material over the burner blast tube is not damaged. Also ensure that the electrical and oil leads are not twisted. When refitting push the burner assembly into position and **ensure a good seal**. Refit screws, and tighten them.
6. Replace the Cover Plate **after applying fresh fire cement** and tighten the four screws.
7. Use new Insulating Rope before replacing the hotplates if necessary. **Tighten the 3 retaining screws.**
8. Switch on electrical and oil supply. The Cooker is now ready for operation.



## BURNER TECHNICAL DATA



Motor	90, W, 1 - phase, 2800 rpm. Capacitor 3 uF.
Fan	108 Dia x 42 x 8H.
Pump	Danfoss 9.15 atmospheres (130 psi)
Electric Transformer	S EM 220/14, 600V. 38mA. TV and radio suppressed.
Control	Danfoss
Mounting plate	Standard SIS
Flexible oil line	1/4" x 3ft. long.
Ignition electrodes	Electrodes with porcelain insulation.
Nozzle	Danfoss .55 US Gallons 60 degree hollow pattern.
Fan House	Aluminium die casting
Blast Tube	PLI
Limit Thermostat	Ranco
Control Thermostats	Ranco


### STARTING UP

- Check that the boiler is full of water.
- Check that all valves in the oil line are open and that the filter and oil pump are purged of air.
- Switch on main supply. Burner will attempt to fire (it may be necessary to press the reset button on control box).  
If flame or ignition fails, the control locks out after 10 — 15 seconds and remains in that position until the safety switch is reset manually.
- Check that any time switches and room thermostats associated with the boiler are "on".
- The burner is unlikely to fire correctly until the air has been purged from the pressure side of the pump via the bleed nipple.
- After the system has achieved its operating temperature, a flue gas analysis and check for smoke should be carried out.

- Check the correct position of the Air Shutter, which gives the highest reading of CO<sub>2</sub> without exceeding a smoke of No. 0 - 1. (Bacharach). Refer to the manufacturer's (Bacharach's) instructions. The CO<sub>2</sub> will normally be in the range of 10% - 13%.
- Check the locating plate of inner assembly. It's normally set in forward position. At abnormal pressure in the combustion chamber the nozzle position can be moved backwards via an adjustable locating plate to stabilise the flame. Check the oil connection from storage tank via oil filter.  
The pressure in the pump is factory set. If adjustment is necessary, this must only be done in conjunction with an oil pressure gauge.



# OIL BURNER ELECTRICAL CONTROLS



## Application

Oil burner control type BHO11.1/1 is used for controlling and monitoring single-stage oil burners. In accordance with valid standards (ISO 3544 and DIN 4748) type BHO 11.1/ (with 10 s safety time) must only be used for fired oil quantities less than 30 kg per hour.

The flame is monitored by photo unit type LD. Provided the BHO 11.1 is used with a photo unit type LD codemarked "A" (Code No. 057H2020), 056H2021, 057H2022 and 056H2024) the false illumination requirement is met. Codemarking "A" is stamped on the cable of the photo unit.



## Base

The base of BHO 11.1 is provided with a loop terminal A.

The four neutral terminals, marked N, are internally connected and can be used externally. Also the base is equipped with three connected earth terminals which in turn are connected to the plate at the bottom of the base. The plate has a hole for connection to burners with earth terminals by means of a screw.

The front plate of the base can be removed as shown in fig. 5.

## Electrical connections

If type BHO 11.1 is connected as shown in fig. 1, it gives prepurging in the preignition time.

If it is connected as shown in fig. 2, it gives pre-ignition without prepurging.

## Technical data

Rated voltage:	220 V
Frequency:	50 Hz
Working range:	18 - 64 V
Mains fuse:	Max. 1 A
Enclosure:	IP 44
Ambient temperature:	-20 °C — +70 °C.

## Function

### Normal Start

Preignition and prepurging, or preignition alone: 7 s.  
Oil is released, and the burner operates, if the flame forms within the safety time of 10 s.

Post ignition after oil release:  
BHO 11.1 — 5s.

### False light at start

If light reaches the photo unit during the prepurging time the control will, after both the prepurging time (7 s.) and the safety time (10 s.), cut out without releasing oil after approx. 17 s.

### No flame formation at start

If oil is released and no flame is established the control will cut out within the safety time of 10 s.

### Flame failure in operation

In the event of flame failure in operation the oil supply is cut off and the control starts the burner as described under the heading "Normal start". On flame failure, immediately after the burner start, the control will initiate re-ignition.

## Flame monitoring

The flame is monitored by photo unit type LD.

**Note:** in accordance with the latest ISO and DIN standards, type BHO activates the safety relay if the photo unit is exposed to light in the pre-purging period.

Max. cable length between BHO and LD: 10 m.

Max. ambient temperature for LD: 70 °C.

Note: Heat radiated by the flame can, in some cases, cause higher ambient temperatures than the max. permissible temperature for LD.

## Control of flame signal

The photo current is measured with a d.c. ammeter (moving coil instrument) with is connected in series with the photo unit (fig. e).

Min. current for flame indication: 35 µA.

## OIL PUMP ADJUSTMENTS

### DANFOSS MSLA 032

## Technical Data

### Viscosity range:

1,3 — 18,0 mm<sup>2</sup>/s (cST) at 20 °C.

Speed: 2800 R.P.M.

Factory setting: 9.15 Bar.

Coil voltage: Shown on the coil.

### Connections (Fig. 1)

The pump is to be connected as follows:

Single-line open bypass (Fig. 6)

E = Nozzle line 1/8 in. BSP.F.

S = Suction line 1/4 in. BSP.F.

M = Pressure gauge connection, venting 1/8 in. BSP.F.

### Venting (Fig. 2)

Venting is necessary for single line Burner.

### Pressure setting (Fig. 3)

**Note:** The valve has two functions: A closing function with fixed closing pressure and a regulating function where the pump pressure can be set by means of the pressure regulating screw.

### Dismantle the regulation system (Fig. 4).

1. Dismantle the orifice nipple with valve (A).
2. Remove the pressure regulation spring with the black plastic cover and the pressure cone.
3. When dismantling the pressure setting screw, remove the O-ring (C) and metal ring (D). The setting screw (B) can then be screwed anti-clockwise out of the pump.


**Note:** Orifice nipple and valve are a unit and cannot be dismantled.

### Coil replacement (Fig. 5).




*Danfoss*



**Fig. 1**




**Fig. 2**





**Fig. 3**




**Fig. 4**



**Fig. 5**



**Fig. 6**



14



# Oil-Fired **STANLEY** De-Luxe 90

## FAULT FINDING

- |  |   |   |
|--|---|---|
| 1. Burner Cut Out                          | (a) Lack of Oil<br>(b) High Limit Thermostat<br>(c) Burner Control Box Reset Button   | (a) Refill Tank and Prime Burner Pump<br>(b) Press to Reset<br>(c) If Red Bulb Lighting press to reset  |
| 2. Poor Chimney Draught                    | (a) Obstruction<br>(b) Too Low<br>(c) Too Wide<br>(d) Crack in Wall<br>(e) Shared by another Unit   | (a) Clear and Clean<br>(b) Raise Height above Ridge<br>(c) Fit Flue Liner 15 to 23 cm.<br>(d) Repair Cracks<br>(e) Cut off other Unit.  |
| 3. Excessive Chimney Draught               | (a) High Chimney  | (a) Fit Draught Stabilizer or Cowl.   |
| 4. Down Draught                            | (a) High Trees<br>(b) High Buildings<br>(c) Low Chimney<br>(d) Negative Pressure Zone   | (a) Raise Chimney Height<br>(b) Raise Chimney Height<br>(c) Raise Chimney Height<br>(d) Fit Cowl  |
| 5. Cooker Smoking                          | (a) Insufficient Primary Air<br>(b) Chimney Choked<br>(c) Side Flueways Choked<br>(d) Down Draught  | (a) Provide Room Air Inlet or adjust Burner air intake<br>(c) Clean Flueways<br>(d) Raise Chimney Height or Fit Cowl  |
| 6. Hot Plate not Heating                   | (a) Boiler Baffles incorrectly set<br>(b) Burner Cutting Out<br>(c) Utensils not Flat   | (a) Set Baffles at position B<br>(b) Increase Thermostat Setting<br>(c) Use Machine-based Utensils  |
| 7. Oven not Heating                        | (a) Boiler Baffles incorrectly set<br>(b) Flueways blocked with soot<br>(c) Faulty Thermostat   | (a) Set Baffles at position C.<br>(b) Clean Out<br>(c) Check and replace if necessary   |
| 8. Radiators not Heating                   | (a) Boiler Baffles incorrectly set<br>(b) Pump not working<br>(c) Air in Radiators<br>(d) Pipe system faulty<br>(e) Excessive Number of Radiators<br>(f) Radiator Valves not adjusted   | (a) Set Baffles at position A<br>(b) Check and replace if defective<br>(c) Vent Radiators<br>(d) Check Pipe Sizes and Circuit<br>(e) Turn off unneeded Radiators<br>(f) Adjust Valves to give even flow                     |
| 9. Domestic Hot Water Cylinder not Heating | (a) Cylinder too Large<br>(b) Flow Pipe too small<br>(c) Flow Pipe crossed<br>(d) Cylinder too far away<br>(e) Hot water from Cylinder not reaching Cylinder                            | (a) Use 135 — 180L Cylinder<br>(b) Use 25 mm. Bore Pipe<br>(c) Reverse Flow Pipe<br>(d) Not more than 7.8m fully lagged<br>(e) Adjust Flow Control Valves or fit Injector Tee.  |
| 10. Intermittent Performance               | (a) Cooker starved of Primary Air<br>(b) Extraction Fan in Room<br><br>(c) Dirt in Nozzle<br>(d) Dirty Burner<br>(e) Dirty Flueways<br>(f) Dirty Oil Filter<br>(g) Uncontrolled Burning | (a) Provide Air Inlet in Room<br>(b) Provide additional Air Inlet in Room<br>(c) Clean or Replace Nozzle<br>(d) Service Burner<br>(e) Clean Flueways frequently<br>(f) Clean or Replace<br>(g) Repair or Replace Thermostat |
| 11. Domestic Hot Water Rusty               | (a) Leak in Indirect Cylinder Coil<br>(b) Incorrect Cylinder fitted   | (a) Replace Cylinder<br>(b) Check with Installer  |

It is of the utmost importance to keep the flue pipe and chimney clear of deposits.

Blocked or partially obstructed flueways and chimneys will cause dangerous fumes to be emitted into the room, these may well be invisible.

**Waterford Foundry Limited**

Bilberry  
Waterford  
Ireland

Telephone 051-75911  
Telex 80763